

MONTAGEANLEITUNG COMBIGERÄT

BF 5002-R I

DE

EN

FR

IT

HU


PL






DK



NO

SE









	Combi BF 5002-R I
Artikel-Nr.	127470
	ca. 105 (145) cm x 55 cm x 100 cm
	ca. 45 kg
	B&S 675 EXi Series OHV 2,74 kW / 3200 -1
	13 x 5,00 - 6
	2,2 km/h
	1,1 km/h
	$a_{vhw} = 5,5 \text{ m/s}^2$ (ISO 20643) $k = 0,7 \text{ m/s}^2$
	$L_{WA} = 93 \text{ db(A)}$
	$L_{PA} = 80 \text{ db(A)}$

[illegible]

